
1-1. Key information

Keys

The following keys are provided with the vehicle.



Electronic keys

- Operating the smart access system with push-button start (→P. 4)
- Operating the wireless remote control function (→P.16)
- 2 Mechanical keys
- Key number plate

Using the mechanical key



Take out the mechanical key.

${f n}$ When required to leave a key to the vehicle with a parking attendant

Turn the trunk opener main switch OFF and lock the glove box as circumstances demand. $(\rightarrow P. 23, 213)$

Remove the mechanical key for your own use and provide the attendant with the electronic key only.

n Key number plate

Keep the plate in a safe place such as your wallet, not in the vehicle. In the event that a mechanical key is lost, a new key can be made at your Lexus dealer using the key number plate. $(\rightarrow P.368)$

⚠ NOTICE

n To prevent key damage

- 1 Do not subject the keys to strong shocks, expose them to high temperatures by placing them in direct sunlight, or get them wet.
- 1 Do not expose the keys to electromagnetic materials or attach any material that blocks electromagnetic waves to the key surface.